
Meridian 1

Meridian Integrated Conference Bridge

Description, Installation, administration, and maintenance

Document Number: 553-3001-102

Document Release: Standard 1.00

Date: June 1997

© 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

June 1997

Standard, release 1.00.

Contents

About this document	1
Description	3
System overview	3
MICB description	6
MICB functional characteristics	7
MICB hardware design characteristics	9
MICB operation	15
Configuring the MICB ports	18
Joining the conference	18
Expanding the conference	19
Ending the conference	20
Chairperson's function	20
MICB capacity expansion	22
Security	24
Engineering guidelines	25
System compatibility	25
System resources	26
Required software packages	26
Engineering multiple simultaneous conferences	26
Environmental and power requirements	27
External equipment	29
MICB administration	31
Introduction	31
Logon screen	31

User login	33
General administration procedures	33
Brand line greeting	35
Accessing the Main Menu	36
System Administration menus	38
System Attribute Editor	39
Global Conference Attribute Editor	41
CDN Editor	42
Bridge Allocator	43
Event Script files	46
Brand line Audio Recorder	53
Help display	54
System Maintenance menus	55
System Tests	56
Maintenance Report Browser	56
Short Connection Report	57
Database Archive	58
Database Restore	59
Card Restart	59
Help display	59
Protected Administration	60
Password Editor	60
Functionality Upgrade	61
Software Upgrade	62
Help display	63
Conference Administration	64
Conference Reservation	64
Help display	68
Conference Maintenance	69
Meeting Status Display	71
Meeting Modify	72
Meeting Terminate	73
Meeting Lock	73
Meeting Unlock	74
Help display	74

Chairperson commands	74
Port Maintenance	76
Port Status Display	76
Port Disconnect	77
Help display	78
Report Generation	78
Meeting Log Browser	79
Help display	80
Installation and configuration	81
Quick reference to MICB installation and configuration	81
Installation overview	83
Installation preparation	83
Unpacking and inspection	84
Taking inventory	84
MICB equipment installation	84
Installing the Ethernet Adapter card	85
Installing MICB cards	85
Connecting the terminal to an MICB card in the IPE module	86
Connecting the terminal to Option 11E or 11C cabinet	92
MICB configuration	96
Configuring MICB using the system TTY	96
Configuring MICB using the MMI terminal	100
MICB password security	101
Chairperson tasks	101
Maintenance	103
Maintenance overview	103
Diagnostic tools	103
MICB fault isolation and correction	107
Card replacement	109
Appendix A: MMI error messages and connector pin assignments	111
Brand line file	111

Maintenance terminal cable pin assignments	113
MMI Error Messages	114
Appendix B: Product integrity	119
Reliability	119
Mean time between failures (MTBF)	119
Environment specifications	119
Temperature-related conditions	120
Electrical regulatory standards	121
List of Terms	125